



## OUTRIGGER BRACKETS

1. Using cardboard or similar material, draw a template of brackets.
2. On template, locate center of drawing (per sketch) and draw a vertical line.
3. Place template on wall. Locate one hole. Drill appropriate size hole (see chart). Insert lead shield or thru bolt through template.
4. Using a level and the center line previously drawn, plumb through template and mark remaining holes.
5. Remove template and drill remaining holes.
6. Insert lead shields and place bracket on wall and tighten all bolts or nuts.
7. Install flagpole and tighten any set screws.
8. Locate cleat in convenient spot.
9. For lead shields, drill 1" dia. x 3" deep.
10. For thru bolts, drill 3/4" dia. thru wall.